

MDF Furniture Care Guide

Caring for Your Furniture

Thank you for choosing our furniture. Your piece is crafted from high-quality Medium Density Fiberboard (MDF), an engineered wood product designed for durability, stability, and a smooth painted or laminated finish. With proper care, it will provide years of reliable use.

Everyday Cleaning

- Dust regularly with a soft, dry microfiber cloth.
 - For fingerprints or light dirt, wipe with a slightly damp cloth followed immediately by a dry cloth.
 - Use a mild dish soap diluted in water if additional cleaning is needed.
 - Dry all surfaces thoroughly after cleaning.
-

Avoid Excess Moisture

MDF is sensitive to prolonged exposure to water.

Do:

- Wipe up spills immediately.
- Use coasters under beverages.
- Place trays under plants to prevent water damage.

Don't:

- Leave standing water on the surface.
 - Use soaking wet cloths or mops.
 - Allow water to collect around edges, seams, or hardware.
-

Protect the Surface

To keep your furniture looking its best:

- Use felt pads under decorative items.
 - Lift objects instead of dragging them across the surface.
 - Use placemats, trivets, or protective pads for hot dishes and heavy items.
 - Avoid cutting directly on the furniture.
-

Keep Away from Heat

Excessive heat can damage finishes and adhesives.

Avoid placing your furniture:

- Next to fireplaces
- Near heating vents
- In direct contact with radiators
- Under prolonged direct sunlight

Always use heat-resistant pads beneath hot cookware or appliances.

Sunlight Exposure

Extended exposure to direct sunlight may cause fading or discoloration over time.

For best results:

- Position furniture away from continuous direct sun.
 - Rotate decorative items occasionally to promote even aging.
 - Consider using curtains or blinds in brightly lit rooms.
-

Moving Your Furniture

When relocating your furniture:

- Empty drawers and shelves first.
 - Lift the furniture—never drag it.
 - Lift from the base or structural panels rather than shelves or tabletops.
 - For larger pieces, use two or more people.
-

Indoor Use Only

This furniture is intended for indoor residential use.

Avoid placing it:

- Outdoors
- In garages
- On covered patios
- In damp basements

- In areas with excessive humidity

Recommended indoor humidity: **35–55%**

Hardware Maintenance

Over time, screws and hardware may naturally loosen through normal use.

- Check all hardware every 6–12 months.
 - Tighten screws gently as needed.
 - Do not overtighten, as this may damage the MDF.
-

Avoid Harsh Chemicals

Do **not** use:

- Bleach
- Ammonia-based cleaners
- Acetone
- Paint thinner
- Abrasive powders
- Steel wool
- Scouring pads
- Furniture wax or silicone polish unless specifically recommended

These products may permanently damage the finish.

Weight Guidelines

Use furniture only as intended.

- Distribute heavy items evenly.
 - Avoid sitting or standing on tables, shelves, or cabinets unless specifically designed for that purpose.
 - Do not overload shelves beyond their recommended capacity.
-

Enjoy Your Furniture

With routine cleaning, protection from moisture, and proper use, your MDF furniture will maintain its appearance and performance for years to come.

Thank you for your purchase and for taking care of your furniture.